EMERGENCY EYE WASH STATION

- Contract









EMERGENCY EYE WASH STATION

Description

Effective, sterile and safe eyewashes for industrial use. Tobin's Eyewash Systems are a well proven, quick and safe way to wash chemicals from the eyes.

Chemicals in the eye cause serious damage within 1-5 seconds. Washing that begins within a few seconds can be decisive in minimising eye damage. With Tobin an eye-wash bottle can be within arms' reach to reduce response time.

Tobin's bottle is made to empty under natural pressure, giving a soft flow with 6 streams of sterile saline solution. When the bottom air vent is opened a patient cannot increase the flow by squeezing the bottle.



- Specially designed system for fast application
- Provides soft flow
- Each 1 litre bottle gives approximately 3 minutes washing time
- Includes 2 x 1 litre bottles, cabinet and screws
- 35 (H) x 25 (W) x 11 (D) cm
- 1 litre sterile bottles with 3 years shelf life from time of manufacture

Sterile saline solution of sodium chloride 0.9% in different dispenser formats, for an emergency eyewash.

Specially designed 1 litre bottle.

- Easy extraction, use and application.
- No mechanical parts.
- Disposable (safety).
- Clear instructions for a quick and easy application.
- Date of direction of use in relief (temporary blindness).
- Eye support ring that facilitates the long washing time.
- Smooth flow through 6 tiny jets (strong jets are not recommended) during 3 minutes.
- Expiry date indicating the end of the bottle's useful life.
- Rounded Base (prevents its removal and placement close to other bottles).

Applications and functions:

In all kinds of situations where eye damage may occur that require an immediate response of eyewash in seconds. Mechanical damage (dust, dirt, etc.), splashes of degreasing agents (benzene), acid splashes, alkaline substances splashes (lye, caustic soda, ammonia, lime, cement...). Chemical plants, laboratories, cleaning and maintenance, etc.

medsurge

technics for life











MEDSURGE HEALTHCARE LIMITED

MUSEUM HILL CENTRE, MUSEUM ROAD P.O. BOX 75534 00200 NAIROBI, KENYA Tel: 0720 714 337 Email: info@medsurgehealth.co.ke Web: www.medsurgehealth.co.ke

